

The logo for ALASKA is rendered in a bold, black, sans-serif font. The letters are thick and closely spaced, with a slightly irregular, hand-drawn appearance. The 'A' and 'K' are particularly prominent due to their size and weight. The logo is positioned in the upper right quadrant of the page, set against a white background that is partially framed by a large, grey, curved shape on the left side.

ALASKA

**Gebrauchsanweisung
Heizlüfter FH2012**

Sehr geehrte Kundin Sehr geehrter Kunde

Herzlichen Glückwunsch zum Kauf dieses **ALASKA** Produktes. Wie alle Erzeugnisse von **ALASKA**, wurde auch dieses Produkt aufgrund neuester technischer Erkenntnisse entwickelt und unter Verwendung zuverlässigster und modernster elektrischer/elektronischer Bauteile hergestellt.

Bitte nehmen Sie sich einige Minuten Zeit, bevor Sie das Gerät in Betrieb nehmen, und lesen Sie die nachfolgende Gebrauchsanweisung durch.

Vielen Dank.




QA12-000002936

Hergestellt für:
Fulltrade International GmbH
Schlüterstraße 5
40235 Düsseldorf
Hotline: 0 800 / 503 54 18

INHALTSVERZEICHNIS

Teilleiste	2
Wichtige Sicherheitshinweise	3 - 4
Bestimmungsgemäßer Gebrauch	5
Betrieb	5
Reinigung und Lagerung	6
Technische Daten	6
Gewährleistung	7

TEILLEISTE



WICHTIGE SICHERHEITSHINWEISE



Achtung! Folgende Sicherheitshinweise müssen zur Kenntnis genommen und beachtet werden, um die Unfallgefahr zu verringern.

Gebrauchsanweisung

Vor Inbetriebnahme entsprechende Hinweise und Sicherheitsanweisungen aufmerksam durchlesen. Besonders die Warnungen in dieser Gebrauchsanweisung beachten. Gebrauchsanweisung in Reichweite aufbewahren, um diese bei Bedarf jederzeit zu Rate ziehen können. Bei Weitergabe der Geräte an Dritte diese Gebrauchsanweisung mit aushändigen.

Netzspannung überprüfen

Vor Anschluss an das Stromnetz sicherstellen, dass Netzspannung und Stromart mit den Angaben auf dem Typenschild am Gerät übereinstimmen.

Heiße Oberflächen

Dieser Heizlüfter wird während des Betriebes sehr heiß. Um Verbrennungen zu vermeiden, berühren Sie den Heizlüfter nicht mit der nackten Haut. Halten Sie brennbares Material, wie z. B. Vorhänge, mindestens 1 m vom dem Gerät entfernt.

Vorsicht bei Kindern

Besondere Vorsicht ist erforderlich, wenn der Heizlüfter von Kindern, in der Nähe von Kindern oder von Personen verwendet wird, die die Gefahren nicht erkennen können.

Dieses Gerät ist nicht dafür bestimmt, durch Personen (einschließlich Kinder) mit eingeschränkten physischen, sensorischen oder geistigen Fähigkeiten oder mangels Erfahrung und/oder mangels Wissen benutzt zu werden, es sei denn, sie werden durch eine für ihre Sicherheit zuständige Person beaufsichtigt oder erhielten von ihr Anweisungen, wie das Gerät zu benutzen ist.

Kinder sollten überwacht werden um sicherzustellen, dass sie nicht mit dem Gerät spielen.

Nicht für den Außengebrauch

Dieses Gerät ist nur für den Innengebrauch geeignet.

Von Feuchtigkeit fernhalten

Verwenden Sie den Heizlüfter nicht in der Nähe einer Badewanne, Dusche oder eines Schwimmbeckens. Keine mit Flüssigkeit gefüllten Gegenstände, wie z.B. Vasen, auf das Gerät stellen.

Das Gerät nur in gemäßigten Breitengraden verwenden, Tropen und besonders feuchtes Klima vermeiden.

Von explosionsgefährdeten Bereichen fernhalten

Dieser Heizlüfter enthält heiße Teile und es kann zur Funkenbildung im Inneren des Heizlüfters kommen. Deshalb darf der Heizlüfter nicht in explosionsgefährdeten Bereichen, wie z.B. in Lagerräumen von Benzin, Farben, oder anderer brennbarer Flüssigkeiten, verwendet werden.

Keine Gegenstände in das Gerät eindringen lassen

Führen Sie keine Gegenstände in das Innere des Gerätes ein und lassen Sie keine Fremdkörper in das Gerät eindringen. Es kann zu einem elektrischen Schlag, Feuer oder zu einer Beschädigung des Heizkörpers kommen.

WICHTIGE SICHERHEITSHINWEISE

Verlängerungskabel vermeiden

Vermeiden Sie die Verwendung eines Verlängerungskabels, da dieses überhitzen könnte. Falls ein Verlängerungskabel verwendet werden muss, muss der Durchmesser des Kupferkabels wenigstens 1 mm² betragen und für einen Nennstrom von 10 A ausgelegt sein.

Kabel sicher verlegen

Verlegen Sie das Netzkabel so, dass ein Darüberstolpern vermieden wird. Verlegen Sie es nicht unter einem Teppich o. ä.. Verlegen Sie das Netzkabel in keinem Bereich, in dem sich viele Personen bewegen.

Nicht mit defektem Netzkabel verwenden

Beschädigungen des Netzkabels durch Knicken und Kontakt mit scharfen Kanten vermeiden. Gerät sowie das Anschlusskabel regelmäßig auf evtl. Beschädigungen überprüfen. Verwenden Sie den Heizlüfter nicht, wenn das Netzkabel oder der Netzstecker beschädigt ist. Wenn das Netzkabel beschädigt ist, muss es durch den Hersteller, eine seiner Servicevertretungen oder eine ähnlich qualifizierte Person ersetzt werden, um die Gefahr eines elektrischen Schlags zu vermeiden.

Nur bestimmungsgemäß verwenden

Verwenden Sie den Heizlüfter nur, wie in dieser Gebrauchsanweisung beschrieben. Jede andere Verwendung kann zu Feuer, elektrischem Schlag oder zu Personenschäden führen.

Keine Zeitschaltuhr verwenden

Verwenden Sie diesen Heizkörper mit keiner Zeitschaltuhr oder einem anderen Gerät, das den Heizlüfter automatisch einschaltet.

Reparatur

Auf keinen Fall versuchen, das Gerät selbst zu reparieren. Zur Wartung und Reparatur an einen Fachhändler oder einen qualifizierten Kundendienst wenden. Reparaturen dürfen nur durch einen Fachmann durchgeführt werden.

Luftzufuhr und Luftanfuhr freihalten

Um Feuer zu vermeiden, decken Sie die Lufteinlass- und Luftaustrittsschlitze in keiner Weise ab. Verwenden Sie das Gerät auf keiner weichen Oberfläche, da dadurch die Lufteintritts- oder Luftaustrittsschlitze abgedeckt werden könnten.

Um das Gerät muss mindestens ein Freiraum von 50 cm vorhanden sein.

Bei Nichtgebrauch vom Stromnetz trennen

Trennen Sie den Heizlüfter vom Stromnetz, wenn Sie ihn nicht verwenden.

Nicht für kleine Räume

Dieser Heizlüfter ist nicht für die Verwendung in kleinen Räumen geeignet. Die Raumgröße muss mindestens 4 m² betragen.



Warnung: Um eine Überhitzung zu vermeiden, darf das Gerät nicht abgedeckt werden. Das Heizgerät darf nicht unmittelbar unterhalb einer Wandsteckdose aufgestellt werden.

Warnung: Dieses Heizgerät verfügt über kein Thermostat zur Kontrolle der Zimmertemperatur. Verwenden Sie dieses Heizgerät nicht in kleinen Räumen, in denen sich Personen befinden, die das Zimmer nicht ohne Hilfe verlassen können; es sei denn, sie werden permanent beaufsichtigt.

Benutzen Sie das Heizgerät nicht in der Nähe von Bädern, Duschen oder ähnlichen.

BESTIMMUNGSGEMÄSSER GEBRAUCH


- Das Gerät ist zum Aufwärmen von Räumen mit einer Mindestgröße von 4 m²-geeignet.
- Das Gerät ist ausschließlich für den Privatgebrauch bestimmt und ist nicht für den professionellen Betrieb ausgelegt.
- Verwenden Sie das Gerät nur, wie in dieser Gebrauchsanleitung beschrieben.
- Jede andere Verwendung gilt als nicht bestimmungsgemäß und kann zu Sach- oder Personenschäden führen.
- Der Hersteller übernimmt keine Haftung für Schäden, die durch nicht-bestimmungsgemäßen Gebrauch entstanden sind.

BETRIEB

Stellen Sie sicher, dass der Moduswahlschalter in der Stellung **O** ist.

Stecken Sie den Netzstecker in eine geeignete Steckdose.

Stellen Sie den Moduswahlschalter auf den gewünschten Heiz- oder Ventilator-Modus:

Schalterstellung	Modus	Betriebsanzeige
O	ausgeschaltet	Aus
	Ventilator-Modus (keine Heizwirkung)	Ein
I	Niedrige Heizleistung	Ein
II	Hohe Heizleistung	Ein

Stellen Sie mit dem Temperaturregler die gewünschte Temperatur ein. Je weiter Sie den Temperaturregler im Uhrzeigersinn drehen, je höher ist die eingestellte Temperatur.

Wenn die eingestellte Temperatur höher als die Raumtemperatur ist, schaltet sich der Heizlüfter ein. Sobald die eingestellte Temperatur erreicht ist, schaltet sich der Heizlüfter aus.

Sobald die Raumtemperatur zu weit absinkt, schaltet sich der Heizlüfter automatisch wieder ein.

Schalten Sie nach dem Gebrauch den Moduswahlschalter in die Stellung **O** und drehen Sie den Temperaturregler bis zum Anschlag gegen den Uhrzeigersinn.

Ziehen Sie den Netzstecker.

Sicherheitsabschaltung

Wenn der Heizlüfter überhitzt, schaltet der Überhitzungsschutz das Gerät sofort aus. Um das Gerät wieder zu verwenden, schalten Sie das Gerät aus und ziehen Sie den Netzstecker aus der Steckdose.

Lassen Sie das Gerät abkühlen und beseitigen Sie die Ursache der Überhitzung (z.B. Lufteintrittsöffnung abgedeckt).

Schalten Sie das Gerät wieder, wie oben beschrieben, ein.

REINIGUNG UND LAGERUNG

Reinigung

Vor der Reinigung den Heizlüfter ausschalten, das Netzkabel aus der Steckdose ziehen und den Heizlüfter vollständig abkühlen lassen.

Netzkabel, Stecker oder Heizlüfter nicht in Wasser oder andere Flüssigkeiten tauchen.

Den Heizlüfter mit einem trockenen Tuch abwischen, um Staub zu entfernen. Verwenden Sie ein leicht angefeuchtetes Tuch, um Flecken zu entfernen.

Keine Reinigungsmittel, aggressive Reinigungspulver oder Poliermittel verwenden, um die Oberflächen des Heizlüfters zu reinigen, da dadurch die Oberfläche zerstört werden könnte.

Lagerung

Wenn Sie den Heizlüfter nicht verwenden, lagern Sie ihn an einem kühlen, trockenen Ort. Der Heizlüfter sollte abgedeckt werden, um ihn vor Staub und Schmutz zu schützen.

TECHNISCHE DATEN

Leistungsaufnahme	2000 W
Spannung	220-240 V~
Frequenz	50/60 Hz
Abmessungen	217 x 137 x 267 mm
Gewicht	0,9 kg



Hinweise zum Umweltschutz

Alt-Elektrogeräte sind Wertstoffe, sie gehören daher nicht in den Hausmüll!
Wir möchten Sie daher bitten, uns mit Ihrem aktiven Beitrag bei der Ressourcenschonung und beim Umweltschutz zu unterstützen und dieses Gerät bei den -falls vorhanden- eingerichteten Rücknahmestellen abzugeben.

GEWÄHRLEISTUNG

Für dieses Produkt gilt die gesetzliche Gewährleistung.
Reklamationen sind unmittelbar nach Feststellung zu melden.

Der Gewährleistungsanspruch erlischt bei Eingriffen durch den Käufer oder durch Dritte. Schäden, die durch unsachgemäße Behandlung oder Bedienung, durch falsches Aufstellen oder Aufbewahren, durch unsachgemäßen Anschluss oder Installation sowie durch höhere Gewalt oder sonstige äußere Einflüsse entstehen, fallen nicht unter die Gewährleistung. Wir empfehlen, die Bedienungsanleitung aufmerksam zu lesen, da dort wichtige Hinweise enthalten sind.

Der Gewährleistungsanspruch ist vom Käufer durch Vorlage der Kaufquittung nachzuweisen.

Hinweise:

1. Sollte Ihr Produkt nicht mehr richtig funktionieren, so prüfen Sie bitte vorerst, ob andere Gründe, wie z.B. unterbrochene Stromversorgung oder falsche Handhabung, die Ursache sind.
2. Beachten Sie bitte, dass Sie Ihrem defekten Produkt in jedem Fall folgende Unterlagen beifügen bzw bereit halten:
 - Kaufquittung
 - Gerätebezeichnung / Typ / Marke
 - Beschreibung des aufgetretenen Mangels mit möglichst genauer Fehlerangabe.

Bei Gewährleistungsanspruch oder Störungen wenden Sie sich bitte persönlich an Ihr Verkaufshaus.

GWL 7/08 E/DE

ALASKA

**Instruction manual
Fan heater FH2012**

Dear Customer,

Congratulations on your purchase of this **ALASKA** product. Like all products from **ALASKA**, this product has also been developed on the basis of the latest technical knowledge and produced using reliable and modern electrical/electronic components.

Please take a few minutes before starting operation of the appliance and read the following operating instructions.

Many thanks!




In case of any claims or possible defects which may occur, please address directly to the Distributing Company in your country.

QA12-0000002936

TABLE OF CONTENTS

Part list	2
Important safety instructions	3 - 4
Intended use	5
Operation	5
Cleaning and storage	6
Technical data	6
Guarantee	7

PART LIST



IMPORTANT SAFETY INSTRUCTIONS



Caution! To reduce the chance of causing an injury you should familiarise yourself with, and observe, the following safety instructions.

Instruction manual

Read the respective information and safety instructions carefully before the initial operation.

Pay particular attention to the warnings included in this instruction manual.

Keep the instruction manual within reach so that you can refer to it whenever necessary.

When transferring the appliance to a third party, please pass on this instruction manual as well.

Check the mains voltage

Before connecting to the electricity supply, ensure that the mains voltage supply and type of current correspond to the details on the type plate on the heater.

Hot surfaces

This fan heater becomes very hot during operation. To avoid burning or scalding, do not touch the surface of the fan heater with your bare skin. Keep all flammable material, such as e.g. curtains at a distance of at least 1 m from the heater.

Caution with children

Special care and attention is required if the fan heater is going to be operated by children or if it is near children or people who are unaware of the possible dangers.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Children should be supervised to ensure that they do not play with the appliance.

Unsuitable for outdoor use

This appliance is only suitable for use indoors.

Keep away from moisture

Do not use the fan heater close to a bathtub, shower or a swimming pool. Do not place any items filled with liquid on top of this appliance, such as e.g. vases.

Only use the appliance in moderate latitudes; avoid tropical and particularly damp climates.

Keep away from highly flammable areas

This fan heater contains hot components and it could produce sparks within its body.

Therefore, the fan heater should not be used in highly flammable areas, such as e.g. in rooms where petrol, paints or other flammable liquids are stored.

Do not insert any objects into the housing

Do not insert any objects into the interior of the housing and do not allow any item to fall into the appliance. This can result in electric shock or fire or it could cause damage to the heater.

IMPORTANT SAFETY INSTRUCTIONS

Avoid using extension cables

Avoid using an extension cable, as it could overheat. However, if you do have to use an extension cable, the diameter of the copper cable must be at least 1 mm² and it should be designed for a rated current of 10 A.

Lay the cable safely

Lay the cable in such a way that it does not represent a trip hazard. Do not lay it underneath a carpet or any similar covering. Do not lay the cable in an area which is susceptible to a lot of human traffic.

Do not use with a defective mains cable

Avoid damaging the cable for the mains adapter by bending it and placing it on sharp edges. The heater and the connecting cable should be checked regularly for any damage. Regularly check the power plug and power cord for damage. If the power cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

Only use for its intended purpose

Only use the fan heater in a way that is described in this instruction manual. Any other use can result in fire, electric shock or to personal injury.

Do not use with any timers

Do not use this heater with a timer or any other device that switches the heater on automatically.

Repair

Do not attempt to repair the device yourself under any circumstances. Consult a stockist or a qualified customer service department for repair and maintenance. Repairs should only be implemented by a qualified electrician.

Keep the air intake and air outlet vents clear

To prevent the risk of fire, do not cover the air intake vents or air outlet slots in any way. Do not use the fan heater on soft surfaces which could end up covering the air intake or outlet vents. There must be a space of at least 50 cm around the fan heater.

Disconnect from the electricity when not in use

Disconnect the fan heater from the mains supply when it is not being used.

Not suitable for use in small rooms

This fan heater is not suitable for use in small rooms. The room where the fan heater is to be used must be at least 4 m².



Warning: To avoid overheating, the fan heater should not be covered. Do not place the heating appliance directly under a wall outlet.

Warning: This heater is not equipped with a device to control the room temperature. Do not use this heater in small rooms when they are occupied by persons not capable of leaving the room on their own, unless constant supervision is provided.

Do not use this heater in the immediate surroundings of a bath, a shower or a swimming pool.

INTENDED USE


- This appliance is intended for heating up rooms with a minimal size of 4 m².
- This appliance is only suitable for private household use and it is not designed for commercial purposes.
- Use the appliance only as described in this manual.
- Any other use might lead to damage of the appliance, property or personal injury.
- No liability will be accepted for damage resulting from improper use or non-compliance with this manual.

OPERATION

Ensure that the mode selection switch is in the **O** position.

Insert the plug into a suitable socket.

Set the mode selection switch to the desired heat or fan mode:

Switch position	Mode	Indicator light
O	switched off	Off
	fan mode (no heating)	On
I	low heat setting	On
II	high heat setting	On

Adjust the temperature regulator to set the desired temperature. The more the temperature control knob is turned clockwise, the higher the temperature.

If the adjusted temperature is higher than the ambient temperature, the heater switches itself on. When the temperature you set has been reached, the fan heater switches itself off.

As soon as the room temperature drops too low, the fan heater switches itself on again automatically.

When you have finished using the fan heater, set the mode selection switch to the **O** position and turn the temperature regulator anti-clockwise until it reaches its stop.

Remove the plug.

Safety shut off

If the fan heater overheats, the overheating protection device switches the heater off immediately. To be able to use the fan heater again, switch the heater off and remove the plug from the socket.

Allow the heater to cool completely and determine the cause for the heater overheating (e.g. air intake vents have been covered).

Switch the fan heater back on, as described above.

CLEANING AND STORAGE

Cleaning

Switch the fan heater off before cleaning it and remove the plug from the socket and allow the heater to cool completely.

Do not submerge the mains cable, plug or the fan heater into water or other liquids.

Wipe the fan heater with a dry cloth to remove any dust. Use a lightly moistened cloth to remove any marks or stains.

Do not use any cleaning agents, abrasive cleaning powder or polishes to clean the fan heater as they could cause damage to the heater's surface.

Storage

When you are not using the fan heater, store it in a cool, dry location. The fan heater should be covered to protect it from dust and dirt.

TECHNICAL DATA

Power consumption	2000W
Voltage	220-240V~
Frequency	50/60Hz
Dimensions	217 x 137 x 267mm
Weight	0.9kg



Environmental protection

Discarded electric appliances are recyclable and should not be discarded in the domestic waste! Please actively support us in conserving resources and protecting the environment by returning this appliance to the collection centres (if available).

GUARANTEE

A statutory guarantee applies for this product.

Claims must be submitted immediately after their determination.

The right to guarantee claims expires upon any intervention of the purchaser or third parties. Damages caused by wrong treatment or operation, by false placement or storage, improper connection or installation, as well as force or other external influences are not covered by this guarantee. We recommend careful reading of the operating instructions as it contains important information.

The purchaser must prove the right to guarantee claims by presentation of the purchase receipt.

Note:

1. In case this product does not function correctly, please firstly check if there are other reasons, e.g. interruption of the power supply, or incorrect handling are the cause.
2. Please note that the following documents need to be submitted together with your faulty product:
 - Purchase receipt
 - Model description/Type/Brand
 - Describe the fault and problem as detailed as possible

In the case of a claim for guarantee or defects, please contact the seller personally.

GWL 7/08 E/GB